



**GGG-2810**  
**Modified Magpul Zhukov**  
**Handguard For The**  
**Beretta 1301 Shotgun**

## **Modified Magpul Zhukov Handguard For The Beretta 1301 Shotgun**

### **Installation Instructions**

**Caution: Make Your Beretta Shotgun Safe! Make sure the firearm's magazine tube is empty, the chamber is UNLOADED and the Safety Selector is in the SAFE position. Wear eye protection when disassembling and assembling your shotgun.**

**IMPORTANT CONSIDERATION:** If you are considering installing M-LOK accessories to the Modified Zhukov Handguard, you need to install them prior to the installation of the handguard. If you do install M-LOK accessories, it is imperative that the accessory mounting screws are flush with the T-nut screw hole. This may require that you file or grind down the screws during the installation process. This is necessary to insure that the accessory screws do not interfere with the operation of moving parts of the shotgun inside the hand guard. **The result of interference could lead to a catastrophic failure.**

**Please read through the instructions before doing the installation! It will make it easier.**

1. Remove the nose cone from the front of the hand guard. You will reinstall in # 5
2. Remove the factory magazine cap and/or any magazine tube extension and barrel clamp.
3. Remove the factory hand guard.
4. Place the front of Modified Zhukov handguard so that it is just adjacent to the front of the magazine tube. Now angle the rear of the handguard down away from the shotgun. Now slide the front half over the gas system. Swing or rotate the rear of the handguard up towards the bottom of the shotgun and with some force, snap it over the magazine tube. This may take a good smack, but it will snap over the mag tube. Slide the Zhukov handguard forward past the end of the factory magazine tube. Install the nose cone onto the hand guard. The mating cut out features of the nose cone fit tightly onto the hand guard, so make sure to seat it completely onto the front of the handguard. It may take a little effort.
5. Take a moment to notice the two tabs protruding from the rear of the handguard. They will come into play as you proceed. Slide the handguard rearward toward the receiver making sure the nose cone slides over the factory magazine tube. To properly engage the tabs mentioned above into the receiver, you may have to squeeze the rear portion of the handguard in order to engage the tabs.
6. Install the factory magazine tube cap and/or an extended magazine tube and barrel clamp.
7. Function test the shotgun prior to placing it into service.

**GG&G**

3602 E. 42ND STRAVENUE TUCSON AZ 85713  
800-380-2540 FAX: 520-748-7583  
WEBSITE: GGGAZ.COM E-MAIL: GGGAZ@AOL.COM